

- 1 Insert the glands into the switch box, GFCI wire on the right, Motor wire on the left
 - 2 Start on the R U side of the switch facing you. Black wire from the GFCI in the right middle terminal, White wire from GFCI in the middle same side opposite from the Black wire.
- NOTE: All wire terminals face exposed wire facing up.



- 3 Motor wire:
 - U – Black wire
 - V - Orange
 - Y - Red
 - Z - White



- 4 Tie the Gound wires together
- 5 Pulls wires back so a small amount of wire cover is showing in the box. Tighten the glands
- 6 Tighten the Close the Box